



Semi – automatic loader.

General operation.

Operator places drums at low level and orientates the drum to a pre-set position.

The operator will start the loader which will clamp the drums pneumatically and invert the drum onto the tank washer load area by pneumatic lifting cylinder.



An adapter plate can be provided to cater for drums with varying bung positions.

Supplied with local guarding.

Controls can be integrated for use with additional equipment if necessary.

